# terral VOOLE HEAT | SOUND FIRE

"comfort never exist aithout insulation"



**PRODUCT CATALOGUE** 











**Stone wool** is a natural insulation material obtained with a special process in which volcanic rocks such as basalt, dolomite and diabase are melted at 1400-1600°C and turned into lava and then lava is transformed into fiber and mixed with a binding agent.

**Terrawool** stone wool prevents humidity from being held in buildings and negative effects of it thanks to its low diffusion resistance by acting like a good water repellent.

With its dimensional stability, it is not affected by the temperature transitions that may occur. High temperature resistant Terrawool stone wool insulates heat and sound with a single material. It is also a safe material for fire insulation.

Our production facilities are located in the organized industrial zone of Kayseri-İncesu central district. It is the largest facility of Turkey on a 250 thousand m² of land with 50 thousand m² enclosed area, with its 100% domestic capital. Equipped with advanced technology, the facility can produce in any size and type with 80 thousand tons/ year capacity.

As **Terrawool**, we work to make the end-users who use our materials through all our dealers feel that we are always with them before and after the application. To this end, we will endeavor to produce quality works and give our foremen the courses and in-service trainings and continue these trainings on a regular basis.

**His Tekstil**, our group company and the founder and owner of our factory, was established at the 1st Organized Industrial Zone, Kayseri in 1996 on a 67.000 m<sup>2</sup> of land and has 48.000 m2 of enclosed area and it continues its activity at our ring facility of 66.048 spindle capacity.


The principle of the group is to quality products and to give importance to after-sales service with honesty.







CAPITAL



It can be used in the interior walls, stairs and lift spaces of all kinds of buildings, and for the heat, sound and fire insulation of outer walls that can be coated. It can be used in places where there may be condensation problem depending on the need.

#### **Application principles**

It is used as insulation for heat, sound, fire and acoustic purposes inside the cage systems formed with the wooden and metal carrier constructions. Stone wool plates should stand in vertical direction. If necessary, the insulation should be partially secured to the surface with the suspension pins. It is used with black and yellow fiber glass in areas where acoustic insulation is required. Acoustic walls should be covered with materials with a 50% perforated surface.











| Product Code       | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|--------------------|---------|-----------|------------|----------------|------------|
| TWABL4030          | 40      | 30        | 600 × 1200 | 15             | 10.80      |
| <b>TWABL</b> 4040  | 40      | 40        | 600 × 1200 | 12             | 8.64       |
| TWABL4050          | 40      | 50        | 600 × 1200 | 8              | 5.76       |
| <b>TWABL</b> 4060  | 40      | 60        | 600 × 1200 | 8              | 5.76       |
| <b>TWABL</b> 4070  | 40      | 70        | 600 × 1200 | 6              | 4.32       |
| <b>TWABL</b> 4080  | 40      | 80        | 600 × 1200 | 6              | 4.32       |
| TWABL40100         | 40      | 100       | 600 × 1200 | 4              | 2.88       |
| <b>TWABL</b> 5030  | 50      | 30        | 600 × 1200 | 15             | 10.80      |
| TWABL5040          | 50      | 40        | 600 × 1200 | 12             | 8.64       |
| <b>TWABL</b> 5050  | 50      | 50        | 600 × 1200 | 8              | 5.76       |
| TWABL5060          | 50      | 60        | 600 × 1200 | 8              | 5.76       |
| <b>TWABL</b> 5070  | 50      | 70        | 600 × 1200 | 6              | 4.32       |
| TWABL5080          | 50      | 80        | 600 × 1200 | 6              | 4.32       |
| <b>TWABL</b> 50100 | 50      | 100       | 600 × 1200 | 4              | 2.88       |
| TWABL50120         | 50      | 120       | 600 × 1200 | 4              | 2.88       |
| <b>TWABL</b> 7030  | 70      | 30        | 600 × 1200 | 15             | 10.80      |
| <b>TWABL</b> 7040  | 70      | 40        | 600 × 1200 | 10             | 7.2        |
| <b>TWABL</b> 7050  | 70      | 50        | 600 × 1200 | 8              | 5.76       |
| TWABL7060          | 70      | 60        | 600 × 1200 | 8              | 5.76       |
| <b>TWABL</b> 7070  | 70      | 70        | 600 × 1200 | 6              | 4.32       |
| <b>TWABL</b> 7080  | 70      | 80        | 600 × 1200 | 5              | 3.6        |
| TWABL70100         | 70      | 100       | 600 × 1200 | 4              | 2.88       |
| TWABL70120         | 70      | 120       | 600 × 1200 | 4              | 2.88       |

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.







### **Roof Blanket**

**Product description:** Terrawool stone wool roof blanket produced for heat, sound and fire insulation.

### **Application areas**

### **Application principles**

It is used for heat, sound and fire insulation in roofs such as gable roof, free standing roof and hipped roof.

Once the roof surface is cleaned, the Terrawool Stone Wool Roof Blanket will be laid freely with no openings in the joints. Then the roof door is opened and walkway is constructed with planks on the wedges.

| Product Code      | Density | Thickness | Size (mm)   | N. of Rolls | m²/Package |
|-------------------|---------|-----------|-------------|-------------|------------|
| TWCS4080          | 40      | 80        | 1200 x 5000 | 1           | 6.00       |
| TWCS40100         | 40      | 100       | 1200 x 5000 | 1           | 6.00       |
| <b>TWCS</b> 40120 | 40      | 120       | 1200 x 5000 | 1           | 3.60       |
| TWCS40140         | 40      | 140       | 1200 x 5000 | 1           | 3.60       |

- ▶ It should be done in closed areas in rainy weather.
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ► Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.











### **Furnace Plate**

**Product description:** High temperature resistant, aluminum foil or bare stone wool plates.

### **Application areas**

Since the production is done for the firms manufacturing the furnace (oven), it is applied according to the details created by the producers.

| Product Code     | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|------------------|---------|-----------|------------|----------------|------------|
| TWFL4030         | 40      | 30        | 600 x 1200 | 15             | 10.80      |
| <b>TWFL</b> 4040 | 40      | 40        | 600 x 1200 | 10             | 7.20       |
| TWFL4050         | 40      | 50        | 600 x 1200 | 8              | 5.76       |

- It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ► Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.









As it is produced for the collector manufacturers, it is prepared according to the requirements of the application details.

| Product Code      | Density | Thickness | Size (mm)   | N. of Packages | m²/Package |
|-------------------|---------|-----------|-------------|----------------|------------|
| TWGKL4030         | 40      | 30        | 1100 × 1700 | 9              | 16.83      |
| <b>TWGKL</b> 4040 | 40      | 40        | 1100 × 1700 | 6              | 11.22      |
| TWGKL4050         | 40      | 50        | 1100 × 1700 | 6              | 11.22      |
| TWGKL4030         | 40      | 30        | 1100 × 2130 | 9              | 21.09      |
| TWGKL4040         | 40      | 40        | 1100 × 2130 | 6              | 14.06      |
| TWGKL4050         | 40      | 50        | 1100 × 2130 | 6              | 14.06      |

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- $\blacktriangleright$  Plates should be carefully transported to the application area by two persons.











# **Air Conditioner Plate**


**Product description:** One side is aluminum coated stone wool or bare stone wool sheet. It is applied in all technical channel details requiring heat, sound and fire insulation. Terrawool stone wool can be produced as an air conditioning plate, aluminum foil, yellow fiber glass or black fiber glass cover.

### **Application principles**

Plates are to be fixed through insulation hanger pins that will be fixed outside the air conditioning ducts.

| Product Code     | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|------------------|---------|-----------|------------|----------------|------------|
| TWKL7030         | 70      | 30        | 600 x 1200 | 15             | 10.80      |
| <b>TWKL</b> 7040 | 70      | 40        | 600 x 1200 | 10             | 7.20       |
| <b>TWKL</b> 7050 | 70      | 50        | 600 x 1200 | 8              | 5.76       |

- It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.







# **Foil Air-Conditioner Plate**

**Product description:** It is an aluminum coated stone wool or bare stone wool plate. It is applied in all technical channel details requiring heat, sound and fire insulation. Terrawool stone wool can be produced as an air conditioning plate, aluminum foil, yellow fiberglass or black fiberglass cover.

### **Application areas**


### **Application principles**

It is used for heat, sound and fire insulation in air-conditioning channels and air-conditioning cells.

Plates are to be fixed through insulation hanger pins that will be fixed outside the air conditioning ducts.

| Product Code     | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|------------------|---------|-----------|------------|----------------|------------|
| <b>TWFL</b> 7030 | 70      | 30        | 600 x 1200 | 15             | 10.80      |
| <b>TWFL</b> 7040 | 70      | 40        | 600 x 1200 | 10             | 7.20       |
| <b>TWFL</b> 7050 | 70      | 50        | 600 x 1200 | 8              | 5.76       |

- ▶ It should be done in closed areas in rainy weather.
- It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ► Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.











### **Exterior Plate**

**Product description:** It is a plate, both surfaces of which are bare or one side is covered with black fiberglass, vertically carry itself, used for heat, sound and fire insulation.

#### **Application areas**

Stone wool plates are used in curtain wall systems behind the granite, marble, aluminum, glass facade and glass coating for heat, sound insulation and fire safety.

### **Application principles**

Stone wool plates are installed in cage systems formed by metal construction on the facade walls or by means of wall plugs. Also, in ready-made panel systems, the plates can be installed on the facades as ready-made panels at the site following pre-installation at the factory. In the curtain wall systems, since the ventilation space formed between the carrier construction and the covering material has a chimney effect, it is very important to choose A class fireproof material group as humidity barrier in terms of fire safety.

| Product Code       | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|--------------------|---------|-----------|------------|----------------|------------|
| TWDCL5030          | 50      | 30        | 600 × 1200 | 15             | 10.80      |
| <b>TWDCL</b> 5040  | 50      | 40        | 600 × 1200 | 12             | 8.64       |
| <b>TWDCL</b> 5050  | 50      | 50        | 600 × 1200 | 8              | 5.76       |
| TWDCL5060          | 50      | 60        | 600 × 1200 | 8              | 5.76       |
| <b>TWDCL</b> 5070  | 50      | 70        | 600 × 1200 | 6              | 4.32       |
| <b>TWDCL</b> 5080  | 50      | 80        | 600 × 1200 | 6              | 4.32       |
| TWDCL50100         | 50      | 100       | 600 × 1200 | 4              | 2.88       |
| TWDCL50120         | 50      | 120       | 600 × 1200 | 4              | 2.88       |
| <b>TWDCL</b> 5230  | 52      | 30        | 600 × 1200 | 15             | 3.62       |
| TWDCL5240          | 52      | 40        | 600 × 1200 | 12             | 4.83       |
| <b>TWDCL</b> 5250  | 52      | 50        | 600 × 1200 | 8              | 6.03       |
| <b>TWDCL</b> 5260  | 52      | 60        | 600 × 1200 | 8              | 7.24       |
| <b>TWDCL</b> 5270  | 52      | 70        | 600 × 1200 | 6              | 8.44       |
| <b>TWDCL</b> 5280  | 52      | 80        | 600 × 1200 | 6              | 9.65       |
| TWDCL52100         | 52      | 100       | 600 × 1200 | 4              | 12.06      |
| TWDCL52120         | 52      | 120       | 600 × 1200 | 4              | 14.48      |
| TWDCL10030         | 100     | 30        | 600 × 1200 | 8              | 5.76       |
| TWDCL10040         | 100     | 40        | 600 × 1200 | 6              | 4.32       |
| TWDCL10050         | 100     | 50        | 600 × 1200 | 6              | 4.32       |
| TWDCL10060         | 100     | 60        | 600 × 1200 | 4              | 2.88       |
| TWDCL10070         | 100     | 70        | 600 × 1200 | 4              | 2.88       |
| TWDCL10080         | 100     | 80        | 600 × 1200 | 4              | 2.88       |
| TWDCL100100        | 100     | 100       | 600 × 1200 | 3              | 2.16       |
| TWDCL100120        | 100     | 120       | 600 × 1200 | 2              | 1.44       |
| TWDCL11030         | 110     | 30        | 600 × 1200 | 8              | 5.76       |
| <b>TWDCL</b> 11040 | 110     | 40        | 600 × 1200 | 6              | 4.32       |
| TWDCL11050         | 110     | 50        | 600 × 1200 | 4              | 2.88       |
| TWDCL11060         | 110     | 60        | 600 × 1200 | 4              | 2.88       |
| TWDCL11070         | 110     | 70        | 600 × 1200 | 3              | 2.16       |
| TWDCL11080         | 110     | 80        | 600 × 1200 | 3              | 2.16       |
| TWDCL110100        | 110     | 100       | 600 × 1200 | 3              | 2.16       |
| TWDCL110120        | 110     | 120       | 600 × 1200 | 2              | 1.44       |







| Product Code       | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|--------------------|---------|-----------|------------|----------------|------------|
| <b>TWTL</b> 12050  | 120     | 50        | 600 x 1200 | 4              | 14.33      |
| <b>TWTL</b> 12060  | 120     | 60        | 600 x 1200 | 4              | 17.19      |
| <b>TWTL</b> 12070  | 120     | 70        | 600 x 1200 | 3              | 20.06      |
| <b>TWTL</b> 12080  | 120     | 80        | 600 x 1200 | 3              | 22.92      |
| <b>TWTL</b> 120100 | 120     | 100       | 600 x 1200 | 3              | 28.66      |
| <b>TWTL</b> 120120 | 120     | 120       | 600 x 1200 | 2              | 34.39      |
| <b>TWTL</b> 120150 | 120     | 150       | 600 x 1200 | 2              | 42.98      |

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.









# **Sheathing Slabs**

**Product description:** Bare stone wool slabs produced in accordance with TS EN 13500, resistant to impact strength and compressive strength.

#### **Application areas**

#### **Application principles**

Can be coated with plaster due to tensile and compressive strength. It is used on the facades of the buildings for heat, sound and fire insulation. Loose particles on the building surface should be cleaned by brushing and damaged areas should be repaired with plaster. After all surfaces are ready for insulation, the plumb line of the building is controlled with the help of plumb lines and horizontal ropes, then water insulation profile is placed and the thermal insulation panels should be adhered to the surfaces with various bonding methods. Care should be given so that the adhesive cement materials should not overflow out of the joints. 24 hours later, it will be fastened; respectively corner profiles, plaster, 160 gr/m2 alkaline resistant mesh, correction plaster, priming coat, mineral coating and finally priming exterior paint is applied.

| Product Code       | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|--------------------|---------|-----------|------------|----------------|------------|
| TWML13050          | 130     | 50        | 600 × 1200 | 4              | 2.88       |
| <b>TWML</b> 13060  | 130     | 60        | 600 × 1200 | 4              | 2.88       |
| <b>TWML</b> 13070  | 130     | 70        | 600 × 1200 | 3              | 2.16       |
| <b>TWML</b> 13080  | 130     | 80        | 600 × 1200 | 3              | 2.16       |
| TWML130100         | 130     | 100       | 600 × 1200 | 3              | 2.16       |
| <b>TWML</b> 130120 | 130     | 120       | 600 × 1200 | 2              | 1.44       |
| <b>TWML</b> 130150 | 130     | 150       | 600 × 1200 | 2              | 1.44       |
| <b>TWML</b> 15030  | 150     | 30        | 600 × 1200 | 8              | 5.76       |
| <b>TWML</b> 15040  | 150     | 40        | 600 × 1200 | 6              | 4.32       |
| <b>TWML</b> 15050  | 150     | 50        | 600 × 1200 | 4              | 2.88       |
| <b>TWML</b> 15060  | 150     | 60        | 600 × 1200 | 4              | 2.88       |
| <b>TWML</b> 15070  | 150     | 70        | 600 × 1200 | 3              | 2.16       |
| <b>TWML</b> 15080  | 150     | 80        | 600 × 1200 | 3              | 2.16       |
| <b>TWML</b> 150100 | 150     | 100       | 600 × 1200 | 3              | 2.16       |
| <b>TWML</b> 150120 | 150     | 120       | 600 × 1200 | 2              | 1.44       |

- It should be done in closed areas in rainy weather.
- ullet Stretch the canvas even when hey are shipped for short distances.
- $\blacktriangleright$  It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc.
- ► The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.





### **Panel Board**

**Product description:** It is specially produced for heat, sound and fire safety and sandwich panel manufacturing.

### **Application areas**

### **Application principles**


It is used in all industrial buildings, storage areas, and roof and facade panels for heat, sound and fire safety.

Since it is intended for the firms manufacturing sandwich roof and facade, it is produced depending on the details of the manufacturing companies.

| Product Code      | Density | Thickness | Size (mm)   | N. of Packages | m²/Package |
|-------------------|---------|-----------|-------------|----------------|------------|
| <b>TWPL</b> 9075  | 90      | 75        | 1200 x 2000 | 28             | 67.20      |
| <b>TWPL</b> 9080  | 90      | 80        | 1200 x 2000 | 28             | 67.20      |
| <b>TWPL</b> 9085  | 90      | 85        | 1200 x 2000 | 25             | 60.00      |
| <b>TWPL</b> 90100 | 90      | 100       | 1200 x 2000 | 22             | 52.80      |

- · 120 kg/m3 panel plate is produced.
- Plates in size of 1000 x 2000 mm are produced.

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- $\blacktriangleright$  It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ► Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- $\blacktriangleright$  Plates should be carefully transported to the application area by two persons.











# Floating Type Floor Plate

**Product description:** It is a bare stone wool plate produced for areas that require compressive strength and require load bearing, sound insulation, vibration and fire resistance.

### **Application areas**

### **Application principles**

It is used for the floors of the buildings, floors between floors and under the vibration source base for the purpose of heat, sound and vibration insulation.

Plates placed on the floor are bonded to the lateral walls of the floor up to the height of the leveling concrete to prevent vibration transfer. Before the trowel coating is poured, it should be covered with a polyethylene fabric. When it is supported with wire and reinforcements (PP fiber), a layer without shrinking cracks will be obtained. Then the application is completed by covering the desired flooring material.

| Product Code       | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|--------------------|---------|-----------|------------|----------------|------------|
| TWYDL15025         | 150     | 25        | 600 x 1200 | 8              | 5.76       |
| <b>TWYDL</b> 15030 | 150     | 30        | 600 x 1200 | 6              | 4.32       |
| <b>TWYDL</b> 15035 | 150     | 35        | 600 x 1200 | 6              | 4.32       |

- ▶ It should be done in closed areas in rainy weather.
- $\mbox{\Large\ensuremath{\blacktriangleright}}$  Stretch the canvas even when hey are shipped for short distances.
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.







# **Industrial Plates**

**Product description:** It is used for insulation of very high temperatures, industrial facilities, process equipment, steel construction structures, all kinds of technical details requiring heat insulation and fire safety.


### **Application areas**

### **Application principles**

It is used for heat, sound and fire insulation in steel constructions, industrial plants, process equipment. Application surfaces; After the insulation is made ready for the coating by means of hanging pins or carrier hoops, the plates are installed and the sheet metal coatings are made. It is also used in ready panel applications of industrial plates

| Product Code       | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|--------------------|---------|-----------|------------|----------------|------------|
| TWSL7030           | 70      | 30        | 600 × 1200 | 15             | 10.80      |
| <b>TWSL</b> 7040   | 70      | 40        | 600 × 1200 | 10             | 7.20       |
| <b>TWSL</b> 7050   | 70      | 50        | 600 × 1200 | 8              | 5.76       |
| TWSL7060           | 70      | 60        | 600 × 1200 | 8              | 5.76       |
| <b>TWSL</b> 7070   | 70      | 70        | 600 × 1200 | 6              | 4.32       |
| <b>TWSL</b> 7080   | 70      | 80        | 600 × 1200 | 5              | 3.60       |
| <b>TWSL</b> 70100  | 70      | 100       | 600 × 1200 | 4              | 2.16       |
| <b>TWSL</b> 70120  | 70      | 120       | 600 × 1200 | 3              | 2.88       |
| TWSL10030          | 100     | 30        | 600 × 1200 | 8              | 5.76       |
| TWSL10040          | 100     | 40        | 600 × 1200 | 6              | 4.32       |
| TWSL10050          | 100     | 50        | 600 × 1200 | 6              | 4.32       |
| TWSL10060          | 100     | 60        | 600 × 1200 | 4              | 2.88       |
| <b>TWSL</b> 10070  | 100     | 70        | 600 × 1200 | 4              | 2.88       |
| <b>TWSL</b> 10080  | 100     | 80        | 600 × 1200 | 3              | 2.16       |
| TWSL100100         | 100     | 100       | 600 × 1200 | 3              | 2.16       |
| <b>TWSL</b> 100120 | 100     | 120       | 600 × 1200 | 2              | 1.44       |
| <b>TWSL</b> 11030  | 110     | 30        | 600 × 1200 | 8              | 5.76       |
| <b>TWSL</b> 11040  | 110     | 40        | 600 × 1200 | 6              | 4.32       |
| <b>TWSL</b> 11050  | 110     | 50        | 600 × 1200 | 4              | 2.88       |
| <b>TWSL</b> 11060  | 110     | 60        | 600 × 1200 | 4              | 2.88       |
| <b>TWSL</b> 11070  | 110     | 70        | 600 × 1200 | 4              | 2.88       |
| <b>TWSL</b> 11080  | 110     | 80        | 600 × 1200 | 4              | 2.88       |
| <b>TWSL</b> 110100 | 110     | 100       | 600 × 1200 | 3              | 2.16       |
| <b>TWSL</b> 110120 | 110     | 120       | 600 × 1200 | 2              | 1.44       |

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ightharpoonup Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.











# **Industrial Blankets**

**Product description:** High temperature resistant, bare or aluminum foil coated stone wool blankets. It is used in all technical details requiring heat, sound and fire insulation.

### **Application areas**

It is used in industrial facilities of high temperatures, technical equipment, air-conditioning channels, steel constructions, chimneys and heating boilers for heat, sound and fire insulation purposes.


### **Application principles**

First, stone wool blanket is placed on supporter surfaces to be made with insulation hanger pin and hoops and used as the protector of sheet metal covering.

| Product Code      | Density | Thickness | Size (mm)   | N. of Packages | m²/Package |
|-------------------|---------|-----------|-------------|----------------|------------|
| <b>TWSS</b> 8050  | 80      | 50        | 1200 x 8000 | 1              | 9.60       |
| <b>TWSS</b> 8060  | 80      | 60        | 1200 x 8000 | 1              | 9.60       |
| TWSS8080          | 80      | 80        | 1200 x 8000 | 1              | 6.00       |
| <b>TWSS</b> 80100 | 80      | 100       | 1200 x 8000 | 1              | 3.60       |
| <b>TWSS</b> 80120 | 80      | 120       | 1200 x 8000 | 1              | 3.60       |
| <b>TWSS</b> 80140 | 80      | 140       | 1200 x 8000 | 1              | 3.60       |

<sup>·</sup> Terrawool industrial blankets are produced in densities of 90 and 125 kg/m³.

- It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.







# **Industrial Blanket (Rabitz Wire)**

**Product description:** High temperature resistant, stitched, Rabitz wire coated heat and fire insulation mattress.

### **Application areas**

It is used for heat and fire insulation in big diameter pipes, industrial plants and process equipment.

### **Application principles**

Terrawool Stone Wool Industrial Blankets provide heat and fire insulation in places with high fire resistance. It is wounded on large diameter pipes and the joints are passed through the Rabitz wire of the galvanized wires and sewn. On large surfaces, it is applied in the form of insertion lathes. Sheet metal is coated for the protection.

| Product Code       | Density | Thickness | Size (mm)   | N. of Packages | m²/Package |
|--------------------|---------|-----------|-------------|----------------|------------|
| <b>TWRTS</b> 9030  | 90      | 30        | 1200 x 8000 | 1              | 9.60       |
| <b>TWRTS</b> 9040  | 90      | 40        | 1200 x 8000 | 1              | 9.60       |
| <b>TWRTS</b> 9050  | 90      | 50        | 1200 x 8000 | 1              | 6.00       |
| <b>TWRTS</b> 9060  | 90      | 60        | 1200 x 8000 | 1              | 6.00       |
| <b>TWRTS</b> 9080  | 90      | 80        | 1200 x 8000 | 1              | 3.60       |
| <b>TWRTS</b> 90100 | 90      | 100       | 1200 x 8000 | 1              | 3.60       |
| <b>TWRTS</b> 8030  | 80      | 30        | 1200 x 8000 | 1              | 9.60       |
| <b>TWRTS</b> 8040  | 80      | 40        | 1200 x 8000 | 1              | 9.60       |
| TWRTS8050          | 80      | 50        | 1200 x 8000 | 1              | 6.00       |
| TWRTS8060          | 80      | 60        | 1200 x 8000 | 1              | 6.00       |
| TWRTS8080          | 80      | 80        | 1200 x 8000 | 1              | 3.60       |
| TWRTS80100         | 80      | 100       | 1200 x 8000 | 1              | 3.60       |

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.







# **Terraced Roof Plate**


**Product description:** Bare stone wool plates produced with high compression strength for terrace roofs and walkways and for metal and wooden roofs of various slopes.

#### **Application areas and principles**

After the surface finish is made on the terraces and terrace roofs, the joints of the vapor barrier material will be glued by overlapping 10 cm. Then, the stone wool terrace plate will be laid on the surface and the polyethylene sheet will be laid on top. Slope concrete with trowel coating will be poured. After the corner bevels are completed, the waterproofing process will be blocked by overlapping the joints with the bitumen sheeting such as PVC, TPO or EPDM membranes and turning them into the parapets by gluing and sealing. After the water intake test, geotextile felt will be laid and protection and coating layers will be made. On top of the trapezoid metal roof, a layer of vapor barrier polyethylene will be placed by overlapping joints by 10 cm. Single or double layer of stone wool plates will be fixed with trapezoidal screws. In cases where it is applied in 2 layers, stone wool is applied vertically and horizontally. As waterproofing layer, PVC, TPO or EPDM membranes is applied.

| Product Code       | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|--------------------|---------|-----------|------------|----------------|------------|
| <b>TWTCL</b> 15030 | 150     | 30        | 600 x 1200 | 8              | 5.76       |
| TWTCL15040         | 150     | 40        | 600 x 1200 | 6              | 4.32       |
| TWTCL15050         | 150     | 50        | 600 x 1200 | 4              | 2.88       |
| TWTCL15060         | 150     | 60        | 600 x 1200 | 4              | 2.88       |
| TWTCL15080         | 150     | 80        | 600 x 1200 | 3              | 2.16       |
| TWTCL150100        | 150     | 100       | 600 x 1200 | 3              | 2.16       |
| TWTCL150120        | 150     | 120       | 600 x 1200 | 2              | 1.44       |

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc.
- ► The storage floor must be flat and non-slippery.
- Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.







# Internal, Wall Heat Insulation Panel

**Product description:** It is produced as high density stone wool panel with heat, sound and fire safety.

#### **Application areas**

It is used as heat, sound and fire insulation on the inner surface of the exterior walls of buildings, on the adjacent walls of the stairways and elevator spaces, and inside the wooden carcass structures.

### **Application principles**

It is produced for the companies of plaster panel and OSB type panel. Application principles vary according to the details requested by the plaster panel manufacturers.

| Product Code         | Density | Thickness | Size (mm)   | N. of Packages | m²/Package |
|----------------------|---------|-----------|-------------|----------------|------------|
| <b>TWIDIYP</b> 11030 | 110     | 30        | 1200 x 2700 | 5              | 16.20      |
| <b>TWIDIYP</b> 11040 | 110     | 40        | 1200 x 2700 | 4              | 12.96      |
| <b>TWIDIYP</b> 11050 | 110     | 50        | 1200 x 2700 | 3              | 9.72       |

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.











# Fire Door Plate


**Product description:** It is produced as a stone wool plate that provides fire resistance (E160) for fire door manufacturing.

### **Application principles**

As it is intended for the companies producing fire doors, it is applied in one piece depending on the details of the manufacturer.

| Product Code | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|--------------|---------|-----------|------------|----------------|------------|
| TWYKL15060   | 150     | 60        | 950 x 2100 | 1              | 63.84      |

- It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ${\blacktriangleright}$  Plates should be carefully transported to the application area by two persons.





# **Ship Plates**

**Product description:** It is a self-standing, high temperature resistant, bare stone wool plate.

### **Application areas**

It is used for ship and marine construction areas, cofferdam walls, fire doors, fire compartments and interior installations of the vessels.

### **Application principles**

Fixing pins are fastened to the application surfaces by means of spacers and metal elements.

| Product Code        | Density | Thickness | Size (mm)  | N. of Packages | m²/Package |
|---------------------|---------|-----------|------------|----------------|------------|
| TWMFGL4530          | 45      | 30        | 600 x 1200 | 15             | 10.80      |
| TWMFGL4540          | 45      | 40        | 600 x 1200 | 10             | 7.20       |
| TWMFGL4550          | 45      | 50        | 600 x 1200 | 8              | 5.76       |
| TWMFGL4560          | 45      | 60        | 600 x 1200 | 7              | 5.04       |
| <b>TWMFGL</b> 11030 | 110     | 30        | 600 x 1200 | 10             | 7.20       |
| <b>TWMFGL</b> 11040 | 110     | 40        | 600 x 1200 | 6              | 4.32       |
| <b>TWMFGL</b> 11050 | 110     | 50        | 600 x 1200 | 5              | 3.60       |
| <b>TWMFGL</b> 11060 | 110     | 60        | 600 x 1200 | 4              | 2.88       |
| <b>TWMFGL</b> 14030 | 140     | 30        | 600 x 1200 | 8              | 5.76       |
| <b>TWMFGL</b> 15030 | 150     | 30        | 600 x 1200 | 8              | 5.76       |
| <b>TWMFGL</b> 15040 | 150     | 40        | 600 x 1200 | 6              | 4.32       |
| <b>TWMFGL</b> 15050 | 150     | 50        | 600 x 1200 | 5              | 3.60       |
| <b>TWMFGL</b> 15060 | 150     | 60        | 600 x 1200 | 5              | 3.60       |

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ It should be stored in the package and the damaged package should not be
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.







# **Ship Blankets**

**Product description:** It is a self-standing, high temperature resistant, bare stone wool plate.

### **Application areas**

**Application principles** 

It is used for ship and marine construction areas, cofferdam walls, fire doors, fire compartments and interior installations of the vessels. Fixing pins are fastened to the application surfaces by means of spacers and metal elements

| Product Code      | Density | Thickness | Size (mm)   | N. of Packages | m²/Package |
|-------------------|---------|-----------|-------------|----------------|------------|
| <b>TWGS</b> 3250  | 32      | 50        | 1200 x 5000 | 1              | 6.00       |
| <b>TWGS</b> 3260  | 32      | 60        | 1200 x 5000 | 1              | 6.00       |
| <b>TWGS</b> 3280  | 32      | 80        | 1200 x 5000 | 1              | 3.60       |
| <b>TWGS</b> 32100 | 32      | 100       | 1200 x 5000 | 1              | 3.60       |

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ► Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.







# Ship Blanket (Rabitz Wire)

**Product description:** It is a self-standing, high temperature resistant, bare stone wool plate.

#### **Application areas**


### **Application principles**

It is used for ship and marine construction areas, cofferdam walls, fire doors, fire compartments and interior installations of the vessels.

Fixing pins are fastened to the application surfaces by means of spacers and metal elements.

| Product Code      | Density | Thickness | Size (mm)   | N. of Packages | m²/Package |
|-------------------|---------|-----------|-------------|----------------|------------|
| <b>TWMF</b> 12530 | 125     | 30        | 1000 x 8000 | 1              | 8.00       |
| <b>TWMF</b> 12540 | 125     | 40        | 1000 x 8000 | 1              | 8.00       |
| <b>TWMF</b> 12550 | 125     | 50        | 1000 x 8000 | 1              | 5.00       |
| <b>TWMF</b> 12560 | 125     | 60        | 1000 x 8000 | 1              | 5.00       |

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ▶ Storage area should be closed to prevent leakage during rain, flooding etc.
- $\blacktriangleright$  The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.











### **Bulk Stone Wool**

**Product description:** It is a stone wool fiber material that is produced without using binders and resistant to high temperatures, not having a certain form and it is used in the areas where the plate or blanket is not used.


### **Application areas**

It is used in uneven surfaces requiring high temperature resistance, double-walled doors, laboratory devices and electrical home appliances, building components, power cable and installation passages.

### **Application principles**

Terrawool Bulk stone wool should be applied to the areas without leaving any spaces. The average density of the insulation is 80 kg/m<sup>3</sup>.

- ▶ It should be done in closed areas in rainy weather.
- ▶ Stretch the canvas even when hey are shipped for short distances.
- ▶ It should be stored in the package and the damaged package should not be used.
- ▶ Packages should not be stacked on top of each other.
- ▶ The products are not be stepped on or used as a step.
- ▶ Before pulling with rope, hard cardboard with dimensions of 50x20 cm size should be placed under the rope.
- ► Storage area should be closed to prevent leakage during rain, flooding etc.
- ▶ The storage floor must be flat and non-slippery.
- ▶ Loading and unloading should be done with the roof crane.
- ▶ Plates should be carefully transported to the application area by two persons.








































































**Heat Insulation and Energy Efficiency** 



Fire Insulation and **Safety** 



Sound Insulation and Comfort



**Water Vapor Permeability** 

**AUTHORIZED DISTRIBUTOR**